

AUTOMATIC LAUNDRY

www.automaticlaundry.com

Washing Instructions

1



Add detergent, load clothes loosely into washer, and close lid.

2



Insert Coins.

3



Select cycle and temperature and press "Start".

To request service, please go to
www.automaticlaundry.com or call us at 800.422.5833